



Note 1: For most uses, connect AGND to GND.

Note 2: The AGND connection between R5 and R6 is inadequate at high frequencies. Connect these points with a direct wire.

Note 3: Omit U1 if AD9102 is used.

Note 4: Optional SMA connector is for convenient off-board connection.

Note 5: Size is 1.5" x 0.8". To print, use Scale=1.1, x offset = -600, y offset = 1200.